

Draft generic risk assessment for draft standard rules set number SR2009No18

Standard Facility:	Waste Operation: Use of waste to manufacture timber or construction products
Location:	Applies to all potential locations.
Location of environmentally sensitive sites (km / m):	Greater than 500m (see below)
Risk assessment carried out by:	Environment Agency
Date:	16-Feb-09

The scope of the permit and associated rules is defined by the following risk criteria:

- Parameter 1 Permitted activities - The storage of waste (R13) and treatment comprising manufacture of timber and construction Products only(R3,R4,R5).
- Parameter 2 Permitted waste types - Non Hazardous as listed in Rules
- Parameter 3 Quantity of waste accepted at the facility: <75,000 tonnes per annum.
- Parameter 4 The activities shall not be carried out within an Air Quality Management Area (AQMA) designated for particulate matter in the form of PM10.
- Parameter 5 Specified waste shall be stored and treated on an impermeable surface with sealed drainage system when located within groundwater source protection zones 1
- Parameter 6 The only point source discharges to controlled waters or groundwater, are surface water from the roofs of buildings and from areas of the facility not used for the storage or treatment of wastes.
- Parameter 7 The activities shall not be carried out within 500m of a European Site (candidate or Special Area of Conservation, proposed or Special Protection Area or Ramsar site) or a Site of Special Scientific Interest (SSSI).
- Parameter 8 The activities shall not take place within 10 metres of any watercourse
- Abbreviations: SR - Standard Rule

Data and information				Judgement				Action (by permitting)	
Receptor	Source	Harm	Pathway	Probability of exposure	Consequence	Magnitude of risk	Justification for magnitude	Risk management	Residual risk
What is at risk? What do I wish to protect?	What is the agent or process with potential to cause harm?	What are the harmful consequences if things go wrong?	How might the receptor come into contact with the source?	How likely is this contact?	How severe will the consequences be if this occurs?	What is the overall magnitude of the risk?	On what did I base my judgement?	How can I best manage the risk to reduce the magnitude?	What is the magnitude of the risk after management? (This residual risk will be controlled by Compliance Assessment).
Local human population	Releases of particulate matter (dusts) and micro-organisms (bioaerosols).	Harm to human health - respiratory irritation and illness.	Air transport then inhalation.	High	Medium	High	Permitted waste types are non hazardous and do not include dusts, powders or loose fibres and have a low potential to produce bioaerosols, but the treatment activities will produce particulate matter so a high magnitude risk is estimated. The permitted level of throughput and potential size of the facility means there is potential for exposure if anyone is living or working close to the site (apart from the operator and employees). There is potential for increased dust generation from permitted activities during prolonged dry periods e.g. summer months.	SR - fugitive emissions of substances.... SR - the operator shall maintain and implement a fugitive emissions management plan. Long term increases in particulate levels are restricted by SR - the activities shall not be carried out within an AQMA designated for PM10.	Low

Data and information				Judgement				Action (by permitting)	
Receptor	Source	Harm	Pathway	Probability of exposure	Consequence	Magnitude of risk	Justification for magnitude	Risk management	Residual risk
What is at risk? What do I wish to protect?	What is the agent or process with potential to cause harm?	What are the harmful consequences if things go wrong?	How might the receptor come into contact with the source?	How likely is this contact?	How severe will the consequences be if this occurs?	What is the overall magnitude of the risk?	On what did I base my judgement?	How can I best manage the risk to reduce the magnitude?	What is the magnitude of the risk after management? (This residual risk will be controlled by Compliance Assessment).
Local human population	As above	Nuisance - dust on cars, clothing etc.	Air transport then deposition	High	Low	Medium	As above. Local residents often sensitive to dust.	As above	Low
Local human population, livestock and wildlife.	Litter	Nuisance, loss of amenity and harm to animal health	Air transport then deposition	Low	Low	Low	Local residents often sensitive to litter, however permitted waste types have low litter potential.	As above. Appropriate measures could include clearing litter arising from the activities from affected areas outside the site.	Very low
Local human population	Waste, litter and mud on local roads	Nuisance, loss of amenity, road traffic accidents.	Vehicles entering and leaving site.	Medium	Medium	Medium	Road safety, local residents often sensitive to mud on roads.	As above. Appropriate measures could include clearing waste, litter and mud arising from the activities from affected areas outside the site.	Low
Local human population	Odour	Nuisance, loss of amenity	Air transport then inhalation.	Low	Low	Low	Local residents often sensitive to odour, however permitted waste types have low odour potential.	SR - emissions shall be free from odour.... SR (if required) - odour management plan.	Very low
Local human population	Noise and vibration	Nuisance, loss of amenity, loss of sleep.	Noise through the air and vibration through the ground.	Medium	Medium	Medium	Local residents often sensitive to noise and vibration	SR - emissions shall be free from noise and vibration..... SR (if required) - noise and vibration management plan.	Low
Local human population	Scavenging animals and scavenging birds	Harm to human health - from waste carried off site and faeces. Nuisance and loss of amenity.	Air transport and over land	Low	Medium	Low	Permitted wastes unlikely to attract scavenging animals and birds but may become nesting / breeding sites.	SR - Scavenging animals, scavenging birds and other pests shall not cause nuisance.....	Very low
Local human population	Pests (e.g. flies)	Harm to human health, nuisance, loss of amenity	Air transport and over land	Low	Medium	Low	Permitted waste types unlikely to attract pests.	As above	Very low
Local human population and local environment	Flooding of site	If waste is washed off site it may contaminate buildings / gardens / natural habitats downstream.	Flood waters	Low	Low	Low	Permitted waste types are inert so any waste washed off site will add to the volume of the local post-flood clean up workload, rather than the hazard.	SR - accident management plan (will include flood risk management).	Very low

Data and information				Judgement				Action (by permitting)	
Receptor	Source	Harm	Pathway	Probability of exposure	Consequence	Magnitude of risk	Justification for magnitude	Risk management	Residual risk
What is at risk? What do I wish to protect?	What is the agent or process with potential to cause harm?	What are the harmful consequences if things go wrong?	How might the receptor come into contact with the source?	How likely is this contact?	How severe will the consequences be if this occurs?	What is the overall magnitude of the risk?	On what did I base my judgement?	How can I best manage the risk to reduce the magnitude?	What is the magnitude of the risk after management? (This residual risk will be controlled by Compliance Assessment).
Local human population and / or livestock after gaining unauthorised access to the waste operation	All on-site hazards: wastes; machinery and vehicles.	Bodily injury	Direct physical contact	Medium	Low	Low	Permitted waste types are non hazardous therefore only a low magnitude risk is estimated	SR - activities shall be managed and operated in accordance with a management system (will include site security measures to prevent unauthorised access).	Low
Local human population and local environment.	Arson and / or vandalism causing the release of polluting materials to air (smoke or fumes), water or land.	Respiratory irritation, illness and nuisance to local population. Injury to staff, fire fighters or arsonists/vandals. Pollution of water or land.	Air transport of smoke. Spillages and contaminated firewater by direct run-off from site and via surface water drains and ditches.	Medium	High	High	Permitted waste types include wood and other flammable materials so a high magnitude risk is estimated.	As above. SR - accident management plan (will include fire and spillages).	Low
Local human population and local environment	Accidental fire causing the release of polluting materials to air (smoke or fumes), water or land.	Respiratory irritation, illness and nuisance to local population. Injury to staff or fire fighters. Pollution of water or land.	As above.	Medium	High	High	As above.	As above (excluding comments on access to waste). Permitted activities do not include the burning of waste.	Low
All surface waters close to and downstream of site.	Spillage of liquids, leachate from waste, contaminated rainwater run-off from waste e.g. containing suspended solids.	Acute effects: oxygen depletion, fish kill and algal blooms	Direct run-off from site across ground surface, via surface water drains, ditches etc.	Low	Low	Low	Permitted waste types do not include sludges or liquids so only a medium magnitude risk is estimated. No point source emissions to water are permitted, but there is potential for contaminated rainwater run-off from wastes stored outside buildings especially during heavy rain.	SR - All liquids shall be provided with secondary containment.... (applies to non- wastes such as fuels). Run-off restricted by SR on fugitive emissions of substances ... , with appropriate measures: storage & treatment on an impermeable surface with sealed drainage. Activities not permitted within 10 metres of any	Very low
All surface waters close to and downstream of site.	As above	Chronic effects: deterioration of water quality	As above. Indirect run-off via the soil layer	Low	Low	Low	Waste types are non-hazardous and inert so harm is likely to be temporary and reversible.	As above	Very low

Data and information				Judgement				Action (by permitting)	
Receptor	Source	Harm	Pathway	Probability of exposure	Consequence	Magnitude of risk	Justification for magnitude	Risk management	Residual risk
What is at risk? What do I wish to protect?	What is the agent or process with potential to cause harm?	What are the harmful consequences if things go wrong?	How might the receptor come into contact with the source?	How likely is this contact?	How severe will the consequences be if this occurs?	What is the overall magnitude of the risk?	On what did I base my judgement?	How can I best manage the risk to reduce the magnitude?	What is the magnitude of the risk after management? (This residual risk will be controlled by Compliance Assessment).
Abstraction from watercourse downstream of facility (for agricultural or potable use).	As above	Acute effects, closure of abstraction intakes.	Direct run-off from site across ground surface, via surface water drains, ditches etc. then abstraction.	Low	Low	Low	Watercourse must have medium / high flow for abstraction to be permitted, which will dilute contaminated run-off.	As above	Very low
Groundwater	As above	Chronic effects: contamination of groundwater, requiring treatment of water or closure of borehole.	Transport through soil/groundwater then extraction at borehole.	Low	Low	Low	Permitted wastes unlikely to contaminate groundwater.	As above	Very low
Local human population	Contaminated waters used for recreational purposes	Harm to human health - skin damage or gastrointestinal illness.	Direct contact or ingestion	Low	Medium	Low	Unlikely to occur, but might restrict recreational use.	SR - fugitive emissions of substances....SR - the operator shall maintain and implement a fugitive emissions management plan.	Very low
Protected sites - European sites and SSSIs	Any	Harm to protected site through toxic contamination, nutrient enrichment, smothering, disturbance, predation etc.	Any	Medium	Medium	Medium	Waste operations may cause harm to and deterioration of nature conservation sites.	SR - fugitive emissions of substances....SR - the operator shall maintain and implement a fugitive emissions management plan. At 500 metres or above, the potential hazards from the permitted activities pose a low risk to the broad sensitivity of species and habitats groups. The standard permit only applies at this distance or more. It is also a requirement of an SR.	Low